

 QUICK START

Quick Start Guide

At-a-glance operation for trained operators. This is a summary only — read Sections 1–9 for full detail, safety information and troubleshooting before operating the machine.

1 · START OF DAY

1. Check the **bath level** — top up if low (Fill Bath, Section 4).
2. Switch on at the isolator and **log in** at your level.
3. Set the **temperature** (25–80 °C) and let the bath heat.
4. If the solution is fresh or topped up, run **Degas** with no load.

2 · RUN A CLEANING CYCLE

1. **Load** the basket and **close the lid**.
2. **Select** a program (1–4) on the Home screen.
3. Press the **Start** switch.
4. **Monitor** the cycle on the main screen.
5. At the end, **raise & drain** the basket, then unload.

3 · PAUSE / STOP / RESET

- **Stop** switch — pauses the cycle.
- **Start** again — resumes from where it stopped.
- **Hold Stop 3 s** — resets the process.

WON'T START? CHECK

- Process-tank **level high**
- Pump & heater **feedbacks ON**
- Temp ≤ set point · **RTD healthy**
- **No** surge-arrestor fault

TOWER-LAMP STATUS

- **Green** — running, or ready to start (blinking).
- **Orange** — paused, or maintenance / test in progress.
- **Red + buzzer** — fault / alarm, or lid moving. Full legend: Section 7.

IF AN ALARM APPEARS

1. Note the message on the **Alarms** screen (mute the buzzer there).
2. **Rectify the cause** — see the alarm table in Section 8.
3. Press the **Fault Reset** switch to clear it.

SAFETY ESSENTIALS

- **Never run the bath dry** — heaters and resonators must always be covered by liquid.
- The **lid must be closed** for a cycle to run; keep clear of the powered lid as it moves.
- **Isolate the power** before any service or before opening a panel or filter housing.
- **No acids, halogens or flammables** in the bath — they damage the machine and create hazards.